


Guide for Installation and Enrollment

Precautions for FaceStation F2 installation



Keep out of direct sunlight.



Install it following the optimal height:
FSF2-ODB: 124 cm | FSF2-AB,DB: 127 cm



Operate it within -20°C–50°C (-4°F–122°F).



Do not install it in a dark place.



Do not install where the subject is backlit.

How to enroll Visual Face

FaceStation F2 uses Visual Face taken with a visual camera as a means of authentication. Visual Face is an authentication method that distinguishes it from face templates used in face recognition terminals, allowing users to enroll faces in a variety of convenient ways.

Enroll Visual Face on FaceStation F2



Enroll Visual Face directly on FaceStation F2.



Take a picture using FaceStation F2 or upload an image file.



Take a picture using a mobile device by following the link sent from BioStar 2.




Import a CSV file.

- Note:
- Activate the BioStar 2 Cloud before enrolling Visual Face using a mobile device. It requires the Standard or higher license to use this feature.
 - If the Visual Face enrollment using a mobile device fails, enroll directly on the FaceStation F2.
 - The Visual Face enrollment link sent is only valid for 24 hours.
 - Refer to the BioStar 2 help manual to learn more about each method.

How to take a picture for Visual Face


To use Visual Face correctly, take a picture by following instructions below.

✓ **CORRECT**




* Be facing forward and looking straight at the camera.
* Keep your eyes open.


✗ **INCORRECT**




Raising head up




Lowering head




Eyes closed




Thick makeup




Wearing a mask



Wearing a hat



Smiling



Dark places

Resolution | Larger than 250 x 250 pixels

Image size | Up to 10 MB

Supported format | JPG, JPEG or PNG only

Note: · The Visual Face data of FaceStation F2 are not compatible with face templates of FaceStation 2 or FaceLite.

Suprema Inc.

17F Parkview Tower, 248, Jeongjail-ro, Bundang-gu, Seongnam-si, Gyeonggi-do, 13554, Republic of Korea

T +82 31 783 4502 | www.supremainc.com

©2021 Suprema Inc. Suprema and identifying product names and numbers herein are registered trademarks of Suprema Inc.

All non-Suprema brands and product names are trademarks or registered trademarks of their respective companies. Product appearance, build status and/or specifications are subject to change without notice.